


DESIGN SPECIALTIES

MOUNTING INSTRUCTIONS FOR DESIGN SPECIALTIES ALUMINUM MASONRY & SELECT LINE FIREPLACE DOORS

THESE FIREPLACE DOORS HAVE BEEN FULLY ASSEMBLED AND ADJUSTED PRIOR TO PACKAGING.


DESIGN SPECIALTIES STANDARD HARDWARE




TOOLS REQUIRED:

- 5/16" MASONRY DRILL
- 3/8" WRENCH
- #2 PHILLIPS SCREWDRIVER

PLEASE INSPECT DOOR FOR ANY DAMAGE




STEP 1:
USING 5/16" MASONRY DRILL
PRE DRILL MASONRY 2" TO 6" BACK
FROM FIREPLACE FACE AND 3" - 6" FROM
TOP AND BOTTOM OF OPENING
ON EACH SIDE




PRE-BENDING STRAP AS SHOWN
EASES INSTALLATION

- STEP 2: INSERT LEAD ANCHOR INTO DRILLED HOLES
- STEP 3: REMOVE PACKAGING FROM FIREPLACE DOOR.
- STEP 4: PLACE DOOR AGAINST OPENING
- STEP 5: INSERT CUP END OF STRAP INTO "C" SLOT AND BEND STRAP BACK AGAINST BRICK TO ALIGN WITH ANCHOR (PRE-BENDING STRAP EASES INSTALLATION)
- STEP 6: INSTALL HEX SCREWS AND TIGHTEN USING A 3/8" WRENCH.


COMPLETE ONE SIDE OF DOOR BEFORE DOING THE OTHER SIDE, THIS MAY AVOID
"RACKING" THE DOOR OUT OF ADJUSTMENT



IF ATTACHING
DIRECTLY TO THE LINTEL:
DRILL A 7/32" OR #8
DRILL SIZE HOLE INTO LINTEL
SECURE STRAP TO LINTEL
WITH SELF TAPING "F" POINT
SCREWS




IF ATTACHING TO THE DRAFT
ASSEMBLY:
LOCATE THREADED NUTS ON BACK
OF DRAFT
BEND STRAP AS SHOWN
ATTACH STRAP TO THREADED NUT
WITH 1/4" SCREWS PROVIDED
ANCHOR STRAP TO FIREBOX
FLOOR WITH ANCHOR AND HEX SCREW



7/32" OR # 8 DRILLED HOLE
IN LINTEL



"F" POINT (SELF TAPING) SCREW

OUR FIREPLACE DOORS ARE FULLY ASSEMBLED AND ADJUSTED PRIOR TO LEAVING THE FACTORY. HOWEVER, THE GLASS DOORS MAY HAVE SHIFTED DURING SHIPMENT, REQUIRING AN ADJUSTMENT TO GET THE GLASS DOORS TO HANG PROPERLY.




AFTER INSTALLING THE FIREPLACE DOOR, CHECK HOW DOORS OPERATE. CHECK THE GAPS AT THE CENTER AND BETWEEN THE GLASS DOORS AND THE FRAME. IF THE GAPS ARE THE SAME BUT THE TOPS ARE NOT IN ALIGNMENT, IT MAY BE NECESSARY TO MOVE THE BOTTOM FRAME OVER TO BRING THE TOPS OF THE GLASS DOORS INTO ALIGNMENT. LOOSEN THE MOUNTING STRAPS AND MOVE THE BOTTOM OVER SLIGHTLY UNTIL THE GLASS DOORS ARE IN ALIGNMENT. RETIGHTEN THE MOUNTING STRAP.

IF ONE DOOR STICKS OUT FROM THE OTHER ONE, YOU WILL NEED TO MOVE ONE OF THE CORNERS OF THE FRAME OUT SLIGHTLY. ON THE SIDE THAT THE GLASS DOORS ARE IN FROM THE OTHER DOOR, LOOSEN THE NEAREST MOUNTING STRAP AND PULL THE DOOR FORWARD UNTIL THE DOORS ARE IN ALIGNMENT. RETIGHTEN MOUNTING STRAP.



IF THE GAP BETWEEN THE GLASS AT THE CENTER IS DIFFERENT TOP TO BOTTOM, YOU WILL NEED TO ADJUST THE HINGES. THE GAP SHOULD BE APPROXIMATELY $1/16$ " BETWEEN THE GLASS DOORS AT THE CENTER ($1/8$ " FOR DOORS FOR FACTORY BUILT FIREPLACES). DETERMINE WHICH HINGE IS OUT OF ALIGNMENT. USING A PHILLIPS SCREWDRIVER, LOOSEN THE SCREW THAT HOLDS THE HINGE TO THE FRAME, AND SLIDE THE HINGE OVER SLIGHTLY AND RETIGHTEN. CHECK THE DOOR OPERATION, AND REPEAT THIS PROCEDURE IF NECESSARY.



DESIGN SPECIALTIES MESH CURTAIN INSTALLATION FOR ALUMINUM FIREPLACE DOORS

COMPLETE MESH CURTAIN KIT

1 SMALL SCREW



4 ROD RETAINERS



END BRACKET




BYPASS BRACKET




END BRACKET



2 RODS



LEFT AND RIGHT CURTAINS



NOTE: CURTAINS MAY BE INSTALLED AFTER DOOR IS MOUNTED TO THE OPENING.

1. INSTALL CENTER BYPASS BRACKET TO BACK OF MAGNET STRIKE
2. INSTALL END BRACKETS AS SHOWN
3. INSERT LEFT ROD INTO THE RIGHT SIDE OF THE BYPASS BRACKET AS SEEN FROM THE FRONT.
4. STARTING WITH THE PULL HANDLE ON THE CURTAIN, SLIDE RINGS ONTO ROD. LIFT ROD UP AND PLACE LEFT END OF ROD INTO END BRACKET BETWEEN KEEPING THE LAST OR SECOND LAST CURTAIN RING TO THE OUTSIDE OF THE BRACKET. SLIDE THE ROD OUTWARD UNTIL T CONTACTS THE SIDES OF THE FIREPLACE.
5. REPEAT THIS PROCEDURE FOR THE RIGHT SIDE ROD. IF CURTAINS ARE INSTALLED CORRECTLY, THEY WILL OVERLAP AT THE CENTER WHILE CLOSED.
6. USE THE ROD RETAINERS TO KEEP THE ROD FROM SLIDING IN THE HOLDERS. PLACE ONE ON EACH SIDE OF THE END BRACKETS AS SHOWN

PLACE RETAINERS OVER ROD ON EACH SIDE OF THE END BRACKET TO KEEP ROD IN PLACE



CORRECTLY INSTALLED CURTAIN

GATE MESH DOOR INSTALLATION INSTRUCTIONS FOR ALUMINUM FIREPLACE DOORS

1. INSTALL PIVOT BRACKETS ONTO THE INSIDE OF THE BOTTOM DOOR TRACK AS SHOWN.
2. INSTALL BOTTOM GATE MESH PANEL PIVOT INTO PIVOT BRACKET WITH BRASS WASHER BETWEEN PANEL AND BRACKET. SEE FIG #1
3. PLACE A PIVOT BRACKET ONTO THE TOP GATE MESH PIVOT. TIP PANEL UP SO THE PIVOT BRACKET SLIPS ONTO THE INNER DOOR TRACK AT THE TOP. SNUG SCREWS. REPEAT THIS PROCEDURE FOR THE OTHER SIDE. SEE FIG #2.
4. ADJUST THE PANELS BY LOOSENING SCREWS AND MOVING BRACKETS TO GET THE PANELS TO ALIGN AT THE CENTER. SNUG ALL SCREWS.
5. INSTALL THE CLOSURE BRACKET ONTO THE TOP INSIDE DOOR TRACK. TIGHTEN THE BLACK SCREWS. SEE FIG #3

