


DESIGN SPECIALTIES

ALTERNATIVE INSTALLATION INSTRUCTIONS FOR DESIGN SPECIALTIES CAROLINA MODEL FIREPLACE DOORS FOR MASONRY FIREPLACES

ALTERNATIVE MOUNTING HARDWARE KIT

TOOLS NEEDED:

5/16" MASONRY DRILL
FELT TIPPED MARKER
PHILLIPS SCREWDRIVER
3/8" WRENCH



6" MOUNTING STRAP
4 PCS

1/4" X 1 1/4"
LAG SCREW
4 PCS



#10 LEAD ANCHOR
4 PCS




1/4" X 1/4"
PHILLIPS SCREWS
4 PCS



1. CAREFULLY REMOVE THE FIREPLACE DOOR FROM THE PACKAGING.
2. LOCATE THE MOUNTING HOLES ON THE BACK FRAME.
3. ATTACH THE MOUNTING STRAPS TO THE MOUNTING HOLES ON THE BACK FRAME WITH THE SCREWS PROVIDED.
4. PLACE DOOR ONTO OPENING.
5. USE THE FELT TIPPED MARKER, MARK THE INSIDE OF THE FIREPLACE THROUGH THE SLOTS IN THE MOUNTING BRACKETS.
6. REMOVE THE FIREPLACE DOOR FROM THE OPENING.
7. USING THE 5/16" MASONRY DRILL, DRILL HOLES WHERE THE MARKS ARE INSIDE THE FIREPLACE 1 3/4" DEEP.
8. INSERT LEAD ANCHORS INTO HOLES.
9. PLACE DOOR BACK ONTO OPENING AND USING THE LAG SCREWS PROVIDED, INSERT SCREWS THROUGH BRACKETS AND INTO LEAD ANCHORS. TIGHTEN SCREWS WITH A 3/8" WRENCH.

BEND THE BRACKETS TO CONFORM TO THE DISTANCE FROM THE DOOR TO THE OPENING



DESIGN SPECIALTIES




FIG. #1

2. IF ONE GLASS DOOR IS HIGHER THAN THE OTHER AT THE TOP, YOU MAY HAVE TO ADJUST ONE OF THE DOOR HINGES (FIG. # 5). BEFORE MAKING ANY ADJUSTMENTS, OPEN THE GLASS DOORS AND MAKE SURE THE SCREWS THAT HOLD THE TOP HINGE TO THE GLASS DOOR ARE TIGHT. USE A PHILLIPS SCREWDRIVER TO TIGHTEN. SEE FIG. #2

OUR FIREPLACE DOORS ARE FULLY ASSEMBLED AND ADJUSTED PRIOR TO LEAVING THE FACTORY. HOWEVER, THE GLASS DOORS MAY HAVE SHIFTED DURING SHIPMENT, REQUIRING AN ADJUSTMENT TO GET THE GLASS DOORS TO HANG PROPERLY.

1. IF ONE DOOR STICKS OUT FROM THE OTHER ONE, YOU WILL NEED TO MOVE ONE OF THE CORNERS OF THE FRAME OUT SLIGHTLY. ON THE SIDE THAT THE GLASS DOORS ARE IN FROM THE OTHER DOOR, LOOSEN THE NEAREST MOUNTING STRAP AND PULL THE DOOR FORWARD UNTIL THE DOORS ARE IN ALIGNMENT. RETIGHTEN MOUNTING STRAP. SEE FIG. #1




FIG. #2

THE BOTTOM HINGES ARE HELD ON TO THE FRAME WITH 2 ALLEN HEAD SCREWS. AN ACCESS SLOT IS PROVIDED IN THE BACK FRAME TO EASE ADJUSTMENT. DETERMINE WHICH HINGE IS MISALIGNED, THERE SHOULD BE APPROXIMATELY A 1/16" GAP BETWEEN THE LEFT AND RIGHT DOOR PANELS. SEE FIG. #3




FIG. #3




FIG. #4

3. INSERT A 5/32" ALLEN WRENCH THROUGH THE ACCESS SLOT AND INTO THE HINGE SCREW HEAD. LOOSEN BOTH SCREWS. SEE FIG. #4
 4. LEAVE THE ALLEN WRENCH ENGAGED IN THE SCREW AND CLOSE DOOR AND MOVE DOOR TO ALIGN. CAREFULLY
 5. REOPEN DOOR AND TIGHTEN ONE OF THE SCREWS. THIS PROCEDURE MAY NEED TO BE REPEATED UNTIL GLASS DOOR HANGS CORECTLY. SEE FIG. #4

DESIGN SPECIALTIES

GATE MESH DOOR INSTALLATION INSTRUCTIONS

1. INSTALL PIVOT BRACKETS ONTO THE INSIDE OF THE BOTTOM DOOR TRACK AS SHOWN.
2. INSTALL BOTTOM GATE MESH PANEL PIVOT INTO PIVOT BRACKET WITH BRASS WASHER BETWEEN PANEL AND BRACKET. SEE FIG #1
3. PLACE A PIVOT BRACKET ONTO THE TOP GATE MESH PIVOT. TIP PANEL UP SO THE PIVOT BRACKET SLIPS ONTO THE INNER DOOR TRACK AT THE TOP. SNUG SCREWS. REPEAT THIS PROCEDURE FOR THE OTHER SIDE. SEE FIG #2.
4. ADJUST THE PANELS BY LOOSENING SCREWS AND MOVING BRACKETS TO GET THE PANELS TO ALIGN AT THE CENTER. SNUG ALL SCREWS.
5. INSTALL THE CLOSURE BRACKET ONTO THE TOP INSIDE DOOR TRACK. TIGHTEN THE BLACK SCREWS. SEE FIG #3






FIG #1
INSTALLATION SIDE VIEW




FRONT



LOCATE MAGNET ASSEMBLY ON THE TOP AND BOTTOM CENTER OF THE INNER FRAME


FIG #3

MOVE BRACKET TO ADJUST



DESIGN SPECIALTIES



DESIGN SPECIALTIES MESH CURTAIN INSTALLATION FOR CAROLINA



NOTE: CURTAINS MAY BE INSTALLED AFTER DOOR IS MOUNTED TO THE OPENING.

1. ASSEMBLE BYPASS BRACKET TO ATTACHMENT CLIP AS SHOWN
2. INSTALL CENTER BYPASS BRACKET TO BACK OF MAGNET STRIKE
3. INSTALL END BRACKETS AS SHOWN
4. INSERT LEFT ROD INTO THE RIGHT SIDE OF THE BYPASS BRACKET AS SEEN FROM THE FRONT.
5. STARTING WITH THE PULL HANDLE ON THE CURTAIN, SLIDE RINGS ONTO ROD. LIFT ROD UP AND PLACE LEFT END OF ROD INTO END BRACKET KEEPING THE LAST OR SECOND LAST CURTAIN RING TO THE OUTSIDE OF THE BRACKET.
6. SLIDE THE ROD OUTWARD UNTIL IT CONTACTS THE SIDES OF THE FIREPLACE. REPEAT THIS PROCEDURE FOR THE RIGHT SIDE ROD. IF CURTAINS ARE INSTALLED CORRECTLY, THEY WILL OVERLAP AT THE CENTER WHILE CLOSED.
7. USE THE ROD RETAINERS TO KEEP THE ROD FROM SLIDING IN THE HOLDERS. PLACE ONE ON EACH SIDE OF THE END BRACKETS AS SHOWN

PLACE RETAINERS OVER ROD ON EACH SIDE OF THE END BRACKET TO KEEP ROD IN PLACE



CORRECTLY INSTALLED CURTAIN